

Inserting the Battery

Pull out the battery tray on the side and insert the battery with the "+" side up. FOFA then immediately enters the **Simple Setup mode**. (See **Quick Start** or **Setting Up FOFA**).



Remember, FOFA batteries (2032 type) are **small** and can be swallowed by children and pets - **Caution!**

WARNING - CHOKING HAZARD
Keep batteries out of the reach of Children

The FCC wants you to know

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following conditions: 1. This device may not cause harmful interference; 2. This device must accept any interference received, including interference that may cause undesired operation. This equipment generates and uses radio frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception. It has been type tested and found to comply with the limits for remote control devices in accordance with the specifications in Sub-Parts B and C of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by unplugging the equipment, try to correct the interference by one or more of the following measures.

- Reorient the antenna of the radio/TV experiencing the interference.
- Relocate the equipment with respect to the radio/TV. • Move the equipment away from the radio/TV.
- Plug the equipment into an outlet on a different electrical circuit from the radio/TV experiencing the interference. • If necessary, consult your local dealer for additional suggestions. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.



FOFA[®]XD Chart _____'s things.

Set #	Item #	Attached to

Fill in the Set and Item Number along with the name of the item you attach each FOFA to.

www.FindOneFindAll.com

Limited 90-Day Warranty

This product is warranted by Melbourne Designs, LLC against manufacturing defects in material and workmanship under normal use for 90-Days from the date of purchase from Melbourne Designs. EXCEPT AS PROVIDED HEREIN, Melbourne Designs MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS, FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, Melbourne Designs SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF Melbourne Designs HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, notify Melbourne Designs, LLC. Melbourne Designs will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replace parts and products, and products on which a refund is made, become the property of Melbourne Designs, LLC. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by Melbourne Designs; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Melbourne Designs, LLC
Contact through info@FindOneFindAll.com
www.FindOneFindAll.com

01/08

Need more FOFA's? Looking for information?
Go to

www.FindOneFindAll.com

FOFA[®]XD-Find One, Find All[®]

Key Finder & Remote Control Locators.

With Proximity Detect[™]



Thank you for purchasing Find One, Find All[®]XD (or FOFA[®] for short), the only 2-Way Key Finder and Remote Control Locator with Proximity Detect[™]. FOFA is expandable to 36 unique units and doesn't require a "base" to locate items like previous key finders. Simple to setup and use, use FOFA on your keys, wallet, remotes, cell phones, MP3 players, backpacks, or anything else that you misplace.

If you can't wait to start using your FOFA's, go to **Quick Start**. For a more in-depth understanding of your FOFA's, see **Setting up Your FOFA's**.



Both FOFA[®] shapes work identically and with each other.

Quick Start

Carefully pull out the clear tab of the first FOFA* or slide out the battery tray on the side and insert a battery "+" side up. You will hear a beep, then the LED will begin to flash slowly. This is the Simple Setup mode.

To set the first FOFA, press 1

Pull out the clear tab or insert a battery into the second FOFA* in the same manner as the first.

To set the second FOFA, press 2

Your FOFA's are now programmed as **Items 1 & 2**. That's it! To use, push 2 on the first FOFA to find the second one, push 1 on the second to find the first! You don't have to read any more to use them!

If you have more FOFA's then use 3, then 4 and so on. It does not matter which shape of FOFA you use as what number. Now attach your FOFA's to anything you want to keep track of. If you have more than 6, see **Expanded Setup** to organize them into Sets.

* After pulling out the clear battery tab, you may have to firmly push in the battery tray to center the battery, allowing FOFA to start.

Find One, Find All[®] and FOFA[®] are Registered Trademarks of Melbourne Designs, LLC. Patented.

Setting Up Your FOFA's - Inserting the Battery

Each FOFA comes with one CR2032 type battery. To install the battery:

- Locate the battery tray on the side and pull out.
- Position the battery in the tray with the "+" (i.e. positive) side up. (See picture on reverse side.)
- Gently push in the battery tray.

Simple Setup - Get them going fast!

After a battery is inserted, FOFA will beep and go into the Simple Setup. The LED will begin flashing - FOFA now wants to know what number you want it to be assigned to (1 through 6). Press a single number to program the FOFA to that number. FOFA will now flash and "beep back" your choice to confirm what you selected. If you change your mind you can press and hold the 1 and 3 buttons simultaneously for about 3 seconds to re-enter the Simple Setup. If you have 6 or less FOFA's, the Simple Setup is the quickest way to get them going. If you have more than 6 FOFA's, use the following Expanded Setup. Once done, see **Attach FOFA**.

Expanded Setup - Customize your FOFA's!

FOFA locators are expandable to 36 unique locators. How is this possible with only 6 buttons? Using FOFA's Expanded mode you can make 6 **Sets** of 6 **Items**. This gives you the flexibility to customize your FOFA locators so that each person in the family has a different "Set" of FOFA's. Only FOFA's in the same Set will call each other!

First decide on **Set** numbers and **Item** numbers for each of your FOFA's. *Note that in the Simple mode, FOFA chooses Set 1 as a default for you.* To start, put a battery in the FOFA and push any button to get through the Simple Setup. It does not matter which button at this point.

Next, to get into the Expanded Setup, press and hold the 1 and 2 buttons simultaneously for about 3 seconds. Keep holding them until the LED flashes continuously and a warble beep is emitted. You are now in the **Expanded Setup**.

Now your FOFA wants a **Set** number AND an **Item** Number!

- Press a button (2 thru 6) to program the **Set** number. FOFA will beep and the LED will flash more quickly.
- Now press another button (1 thru 6) to program the **Item** number.

FOFA will beep to confirm your settings. FOFA beeps the number corresponding to the **Set** and then, after a brief pause, beeps the number corresponding to the **Item**. Note that if you did choose Set 1, FOFA will assume you still wanted just the Simple Setup and will not beep the Set number. Next is an example of Expanded programming.

Example of Expanded Setup

To program a FOFA as **Set 2, Item 5**, for example, you would

- ◆ Press and hold the 1 and 2 buttons for about 3 seconds to get into Expanded Mode Setup. The LED flashes slowly
- ◆ Press 2. This programs the Set number. The LED flashes quickly.
- ◆ Press 5. This programs the Item number. FOFA will beep and flash 2 times, pause, and then flash & beep 5 times to confirm the settings.

Important Notes:

- ◆ Removing the battery will cause your FOFA to lose its setting. You will need to re-program it using the steps above.
- ◆ If you do not program FOFA, it will respond to every key press from another FOFA unit. However, the unprogrammed FOFA will enter the Simple Setup when you press any button on it.

Attach FOFA

Each FOFA includes a key ring. In addition, a plastic lanyard and double-sided tape can also be used to attach FOFA to any easily lost object. You can use the lanyard to tie FOFA to items like cell phone cases, purses, mp3 players, etc.

Using FOFA to Find Lost Items

To find an object with a missing FOFA attached, simply locate one of your other FOFA and press one button corresponding to the missing unit in that set. If the object is in range, the FOFA on the missing object will begin to flash and beep.

Important: If a family member is on a different Set and loses *all* their things, you can re-program one of your FOFA's temporarily to *their* Set number to find their things for them! For even more tips see

www.FindOneFindAll.com on the web.

For best results, walk around to find the item you're looking for while repeatedly pressing the appropriate button on the keypad. See **Proximity Detect Feature** for help with buried objects. Reduce or eliminate noises so you can hear the beeping FOFA you are looking for. Keep FOFA from large metal objects and other radio sources that might reduce its range. Weak batteries also reduce range.

**Need some more FOFA's? Have questions?
Contact us at info@FindOneFindAll.com.**

Checking your Setup

You can verify the **Set** and **Item** numbers of each FOFA at any time. Press and hold simultaneously the 5 and 6 buttons, then release. The LED will flash and beep first to indicate the **Set** number, pause, then flash and beep the **Item** number. For example, if the FOFA you are checking is defined as **Set 3, Item 2**, you would hear 3 beeps, a pause, then 2 more beeps.

Note: Using the Simple Setup, your FOFA will only beep the Item number.

Proximity Detect™

When misplaced items are buried in clothes, for example, the loudness of the beeping is understandably reduced. If you cannot hear from your keys, how do you know they are even in the house? Using FOFA's unique "Proximity Detect" feature, you can know your lost item is around, it just needs digging out!

2 Way? No, Really 3-Way! - How Proximity Detect Works.

When you call a FOFA (XD) from another, it does beep and flash as you would expect, but does something else also. It automatically *transmits a radio beacon signal back!* After the FOFA you used to call with has finished transmitting, it "listens" for this beacon signal. When it detects the beacon, it makes a single chirp and starts flashing its own LED light in time with the beacon signal! As the signal gets stronger, this flashing becomes more regular. Don't forget that some surrounding materials, especially metallic ones, can reduce the radio range achieved.

Care Instructions

- Do not allow FOFA to become wet. Wipe dry immediately if it gets wet.
- FOFA may be wiped with a damp cloth to clean. Handle FOFA with care. Do not drop.

Specifications

Power	One CR2032 type battery
Battery life	Approximately 1 year (depends on use)
Transmission Frequency	433 MHz
Transmission Range	Up to 30 Feet (10m)
Dimensions - Keyfob	71 X 30 X 10mm
Dimensions - Card Size	70 X 50 X 6mm

Specifications are typical. Individual units may vary. Specifications are subject to change without notice.

Battery Cautions

Use only new batteries of the required size and type. Dispose of the battery promptly and properly. Do not burn or bury. **Batteries can be harmful or fatal if swallowed. KEEP BATTERIES AWAY FROM CHILDREN AND PETS.**